



INSTALLATION INSTRUCTIONS FOR OVERLAND BED TRAY

	NOTICE Read instructions completely before installing this product. Refer back to the instructions frequently during installation.		CAUTION Flying Object Hazard. Fluid Splash Hazard. Wear safety glasses at all times when working on vehicle.
WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov			

1. Remove any obstructions from the bed and rail system that would impede the bed tray installation. In the truck pictured we had to remove the adjustable bed anchor points.



AP-309158-INS



2. Check to make sure you have all hardware pictured below. Begin by sliding the nut plates into the rail system in the bed as shown. Position the plates close to where you want the rack to be.



3. Using bolts with lock and flat washers, and the help of a friend; position the bed rack and begin to install the bolts. Leave the bolts loose for now.



4. If the rack is narrower than the bed, drop in the provided spacers until the extra space is filled. Once the spacers are dropped in tighten all the bolts.





951-658-7077 | 5356 E. Pine Ave Fresno, CA 93711



Installation is finished

